
- a) What is the duty ratio, D, of the converter? The duty ratio is $D = \frac{V_{IN}}{V_{OUT}} = \frac{5}{20} = \frac{1}{4}$.
- b) Sketch the waveform of the MOSFET drain-to-source voltage, v_{DS} . Label the numerical values of all relevant times and voltages.

First we assume that the MOSFET is on, this means that the voltage accross the inductor is $V_L = V_{IN}$. And that means that $V_DS = 0V$. When the MOSFET is off, we can see that $V_L = V_{IN} - V_{OUT} = -15V$. In this case, $V_{DS} = 20V$



c) Find the DC component of the voltage waveform of art (b). How does this value relate to the value of V_{IN} ? Does this make sense and why? The DC component of this waveform is 15V. This input voltage is 5V. We can do this because our output current will become lower than before. This fact maintains the same power.